

Contents

About This Document.....	ii
1 Document Overview.....	1
1.1 Basic Information.....	1
1.2 Antivirus Scan Report.....	2
2 Plug-In Installation Guide.....	3
2.1 Precautions for Plug-In Installation.....	3
2.2 Preparations.....	4
2.2.1 Preparing the Plug-in.....	4
2.2.2 Verifying the Running System Software Version.....	6
2.2.3 Checking Available Space in the Flash Memory.....	6
2.3 Plug-in Installation Procedure.....	7
2.3.1 Uploading/Downloading the Plug-in to the Device.....	8
2.3.1.1 Uploading the Plug-In to the Switch Functioning as an FTP Server.....	8
2.3.1.2 Downloading the Plug-In to the Switch Functioning as an FTP Client.....	9
2.3.1.3 Downloading the Plug-In to the Switch Functioning as an SFTP Client.....	11
2.3.2 Installing the Plug-in.....	12
2.3.3 Verifying the Installation.....	13
2.4 Uninstalling the Plug-in.....	13
3 Remote Mirroring Operation Guide.....	15
3.1 Remote Mirroring Configuration.....	15
3.1.1 Understanding Remote Mirroring.....	15
3.1.2 Licensing Requirements and Limitations for Remote Mirroring.....	18
3.1.3 Configuring Remote Mirroring.....	24
3.1.3.1 Configuring Remote Port Mirroring.....	24
3.1.3.2 Configuring Remote Traffic Mirroring.....	28
3.1.3.3 Configuring Remote VLAN Mirroring.....	36
3.1.3.4 Verifying the Remote Mirroring Configuration.....	39
3.1.4 Configuration Examples for Remote Mirroring.....	39
3.1.4.1 Example for Configuring Layer 2 Remote Port Mirroring.....	40
3.1.4.2 Example for Configuring Layer 3 Remote Port Mirroring (Through a Layer 3 Network).....	43
3.1.4.3 Example for Configuring Layer 3 Remote Port Mirroring (Through a GRE Tunnel).....	45
3.1.4.4 Example for Configuring Remote Truncated Mirroring (Through a Layer 3 Network).....	48

3.2 Mirroring Configuration Commands.....	51
3.2.1 display observe-port.....	51
3.2.2 display port-mirroring.....	53
3.2.3 display traffic-mirroring.....	55
3.2.4 mirroring observe-port.....	57
3.2.5 mirroring observe-port (VLAN view).....	59
3.2.6 observe-port (remote observing port).....	61
3.2.7 observe-port filter enable.....	68
3.2.8 port-mirroring observe-port.....	69
3.2.9 traffic-mirroring (interface view).....	71
3.2.10 traffic-mirroring (system view).....	73
3.3 FAQ.....	76
3.3.1 Why Does MAC Address Learning Need to Be Disabled When Layer 2 Remote Port Mirroring Is Configured in Some Scenarios?.....	76
4 Remote Mirroring Personal Data Description.....	84