

Contents

1 Antenna Description..... 1

2 Antenna Fundamentals.....3

2.1 Antenna Types..... 3

2.2 Antenna Angle.....5

2.3 Antenna Gain.....6

2.4 Receiver Sensitivity..... 7

2.5 Beamwidth.....8

3 Selection Policy..... 11

4 Safety Precautions..... 35

4.1 General Safety Precautions.....35

4.2 Electrical Safety Precautions..... 36

4.3 Working at Heights..... 38

5 27010209 Indoor 2.4 GHz Single-Polarized Directional Antenna (H88 V47 G7)... 39

5.1 27010209 Technical Specifications.....39

5.2 27010209 Antenna Installation.....42

5.2.1 Accessories and Tools.....42

5.2.2 Wall Mounting.....42

5.2.3 Connecting RF Cables..... 43

6 27010210 Indoor 2.4 GHz Single-Polarized Omnidirectional Antenna (H360 V45 G3).....46

6.1 27010210 Technical Specifications.....46

6.2 27010210 Antenna Installation.....49

6.2.1 Accessories and Tools.....49

6.2.2 Ceiling Mounting..... 49

6.2.3 Connecting RF Cables..... 50

7 27010215 Outdoor 2.4 GHz Single-Polarized Omnidirectional Antenna (H360 V9 G11)..... 53

7.1 27010215 Technical Specifications.....53

7.2 27010215 Installation Precautions.....56

7.3 27010215 Antenna Installation.....57

7.3.1 Accessories and Tools.....57

7.3.2 Pole Mounting.....	58
7.3.3 Connecting RF Cables.....	60
8 27010219 Outdoor 2.4 GHz Single-Polarized Directional Antenna (H120 V7 G15.5).....	64
8.1 27010219 Technical Specifications.....	64
8.2 27010219 Installation Precautions.....	67
8.3 27010219 Antenna Installation.....	68
8.3.1 Accessories and Tools.....	69
8.3.2 Pole Mounting.....	69
8.3.3 Connecting RF Cables.....	73
9 27010223 Outdoor 2.4 GHz Single-Polarized Directional Antenna (H90 V7 G17).....	76
9.1 27010223 Technical Specifications.....	76
9.2 27010223 Installation Precautions.....	79
9.3 27010223 Antenna Installation.....	80
9.3.1 Accessories and Tools.....	81
9.3.2 Pole Mounting.....	81
9.3.3 Connecting RF Cables.....	85
10 27010664 Outdoor 2.4 GHz Dual-Polarized Directional Antenna (H60 V7 G18).....	88
10.1 27010664 Technical Specifications.....	88
10.2 27010664 Installation Precautions.....	92
10.3 27010664 Antenna Installation.....	93
10.3.1 Accessories and Tools.....	94
10.3.2 Pole Mounting.....	95
10.3.3 Connecting RF Cables.....	101
11 27010812 Outdoor 2.4 GHz Dual-Polarized Directional Antenna (H60 V30 G12).....	106
11.1 27010812 Technical Specifications.....	106
11.2 27010812 Installation Precautions.....	109
11.3 27010812 Antenna Installation.....	110
11.3.1 Accessories and Tools.....	111
11.3.2 Pole Mounting.....	112
11.3.3 Connecting RF Cables.....	115
12 27010889 Outdoor 5 GHz Dual-Polarized Directional Antenna (H60 V30 G11.5).....	119
12.1 27010889 Technical Specifications.....	119
12.2 27010889 Installation Precautions.....	122
12.3 27010889 Antenna Installation.....	123
12.3.1 Accessories and Tools.....	124
12.3.2 Pole mounting.....	125

12.3.3 Connecting RF Cables.....	128
13 27010890 Outdoor 5 GHz Dual-Polarized Directional Antenna (H15 V15 G19)	132
13.1 27010890 Technical Specifications.....	132
13.2 27010890 Installation Precautions.....	135
13.3 27010890 Antenna Installation.....	136
13.3.1 Accessories and Tools.....	137
13.3.2 Pole Mounting.....	138
13.3.3 Connecting RF Cables.....	141
14 27010898 Outdoor 2.4 GHz Dual-Polarized Directional Antenna (H60 V7 G16.5)	145
14.1 27010898 Technical Specifications.....	145
14.2 27010898 Installation Precautions.....	148
14.3 27010898 Antenna Installation.....	149
14.3.1 Accessories and Tools.....	150
14.3.2 Pole Mounting.....	150
14.3.3 Connecting RF Cables.....	153
15 27010902 Outdoor 2.4 GHz Single-Polarized Directional Antenna (H120 V6 G14.5)	157
15.1 27010902 Technical Specifications.....	157
15.2 27010902 Installation Precautions.....	160
15.3 27010902 Antenna Installation.....	161
15.3.1 Accessories and Tools.....	161
15.3.2 Pole Mounting.....	161
15.3.3 Connecting RF Cables.....	165
16 27010904 Outdoor 2.4 GHz Dual-Polarized Directional Antenna (H30 V30 G14)	169
16.1 27010904 Technical Specifications.....	169
16.2 27010904 Installation Precautions.....	172
16.3 27010904 Antenna Installation.....	173
16.3.1 Accessories and Tools.....	174
16.3.2 Pole Mounting.....	175
16.3.3 Connecting RF Cables.....	178
17 27010906 Outdoor 5 GHz Dual-Polarized Directional Antenna (H32 V32 G14)	182
17.1 27010906 Technical Specifications.....	182
17.2 27010906 Installation Precautions.....	185
17.3 27010906 Antenna Installation.....	186
17.3.1 Accessories and Tools.....	187
17.3.2 Pole Mounting.....	188
17.3.3 Connecting RF Cables.....	191

18 27010912 Outdoor 5 GHz Single-Polarized Directional Antenna (H100 V5.5 G16)	195
18.1 27010912 Technical Specifications.....	195
18.2 27010912 Installation Precautions.....	198
18.3 27010912 Antenna Installation.....	199
18.3.1 Accessories and Tools.....	200
18.3.2 Pole Mounting.....	200
18.3.3 Connecting RF Cables.....	203
19 27010913 Outdoor 2.4 GHz Single-Polarized Omnidirectional Antenna (H360 V11.5 G8)	207
19.1 27010913 Technical Specifications.....	207
19.2 27010913 Installation Precautions.....	210
19.3 27010913 Antenna Installation.....	211
19.3.1 Accessories and Tools.....	211
19.3.2 Pole Mounting.....	212
19.3.3 Connecting RF Cables.....	214
20 27011016 Outdoor 5 GHz Dual-Polarized Directional Antenna (H9 V9 G23)....	218
20.1 27011016 Technical Specifications.....	218
20.2 27011016 Installation Precautions.....	221
20.3 27011016 Antenna Installation.....	222
20.3.1 Accessories and Tools.....	223
20.3.2 Pole Mounting.....	223
20.3.3 Connecting RF Cables.....	227
21 27011145 Outdoor 5 GHz Dual-Polarized Directional Antenna (H15 V15 G19)	231
21.1 27011145 Technical Specifications.....	231
21.2 27011145 Installation Precautions.....	234
21.3 27011145 Antenna Installation.....	235
21.3.1 Accessories and Tools.....	236
21.3.2 Pole Mounting.....	237
21.3.3 Connecting RF Cables.....	240
22 27011172 Indoor 2.4 GHz & 5 GHz Single-Polarized Omnidirectional Antenna (H360 G3 & H360 G4)	244
22.1 27011172 Technical Specifications.....	244
22.2 27011172 Installation Precautions.....	247
22.3 27011172 Antenna Installation.....	249
23 27011332 Outdoor 2.4 GHz Single-Polarized Omnidirectional Antenna (H360 V32 G3)	250
23.1 27011332 Technical Specifications.....	250
23.2 27011332 Installation Precautions.....	253
23.3 27011332 Installing Antennas.....	254

24 27011333 Outdoor 5 GHz Single-Polarized Omnidirectional Antenna (H360 V20 G5).....	257
24.1 27011333 Technical Specifications.....	257
24.2 27011333 Installation Precautions.....	260
24.3 27011333 Installing Antennas.....	261
25 27011618 Rail Transportation 5 GHz Dual-Polarized Directional Antenna (H30 V30 G14).....	264
25.1 27011618 Technical Specifications.....	264
25.2 27011618 Installation Precautions.....	267
25.3 27011618 Antenna Installation.....	267
25.3.1 Accessories and Tools.....	267
25.3.2 Pole Mounting.....	268
25.3.3 Connecting RF Cables.....	269
26 27011619 Rail Transportation 2.4 GHz Dual-Polarized Directional Antenna (H35 V35 G12).....	274
26.1 27011619 Technical Specifications.....	274
26.2 27011619 Installation Precautions.....	277
26.3 27011619 Antenna Installation.....	277
26.3.1 Accessories and Tools.....	277
26.3.2 Pole Mounting.....	278
26.3.3 Connecting RF Cables.....	279
27 27011668 Outdoor 2.4 GHz and 5 GHz Single-Polarized Omnidirectional Antenna (H360 V33 G4 and H360 V22 G7).....	286
27.1 27011668 Technical Specifications.....	286
27.2 27011668 Installation Precautions.....	289
27.3 27011668 Installing Antennas.....	290
28 27011792 Indoor 2.4 GHz and 5 GHz Dual-Polarized Directional Antenna (H75 V55 G4 and H75 V50 G6).....	292
28.1 27011792 Technical Specifications.....	292
28.2 27011792 Antenna Installation.....	295
28.2.1 Accessories and Tools.....	295
28.2.2 Wall Mounting.....	296
28.2.3 Connecting RF Cables.....	298
29 27012045 Vehicle-Mounted 2.4 GHz & 5 GHz Dual-Polarized Directional Antenna (H75 V65 G5.5 & H80 V40 G6).....	301
29.1 27012045 Technical Specifications.....	301
29.2 27012045 Antenna Installation.....	304
29.2.1 Accessories and Tools.....	304
29.2.2 Wall Mounting.....	304
29.2.3 Connecting RF Cables.....	304

30 27012046 Rail Transportation 5 GHz Dual-Polarized Directional Antenna (H30 V30 G14).....	306
30.1 27012046 Technical Specifications.....	306
30.2 27012046 Antenna Installation.....	309
30.2.1 Accessories and Tools.....	309
30.2.2 Wall Mounting.....	310
30.2.3 Connecting RF Cables.....	312
31 27012048 Rail Transportation 2.4 GHz Dual-Polarized Directional Antenna (H35 V35 G12).....	317
31.1 27012048 Technical Specifications.....	317
31.2 27012048 Antenna Installation.....	320
31.2.1 Accessories and Tools.....	320
31.2.2 Wall Mounting.....	321
31.2.3 Connecting RF Cables.....	322
32 27012050 Vehicle-Mounted 5 GHz Dual-Polarized Directional Antenna (H70 V35 G9).....	329
32.1 27012050 Technical Specifications.....	329
32.2 27012050 Antenna Installation.....	332
32.2.1 Accessories and Tools.....	332
32.2.2 Wall Mounting.....	332
32.2.3 Connecting RF Cables.....	332
33 27012075 Vehicle-Mounted 2.4 GHz & 5 GHz Single-Polarized Directional Antenna (H80 V40 G4 & H80 V40 G6).....	334
33.1 27012075 Technical Specifications.....	334
33.2 27012075 Antenna Installation.....	337
33.2.1 Accessories and Tools.....	337
33.2.2 Wall Mounting.....	337
33.2.3 Connecting RF Cables.....	339
34 27012134 Indoor and Outdoor 2.4 GHz and 5 GHz Dual-Polarized Directional Antenna (H33 V33 G13 and H33 V33 G13).....	340
34.1 27012134 Technical Specifications.....	340
34.2 27012134 Installation Precautions.....	345
34.3 27012134 Antenna Installation.....	347
34.3.1 Accessories and Tools.....	347
34.3.2 Wall Mounting.....	348
34.3.3 Pole Mounting.....	351
34.3.4 Connecting RF Cables.....	355
35 27012140 Rail Transportation 5 GHz Dual-Polarized Directional Antenna (H33 V33 G13).....	360
35.1 27012140 Technical Specifications.....	360
35.2 27012140 Installation Precautions.....	364

35.3 27012140 Antenna Installation.....	365
35.3.1 Accessories and Tools.....	366
35.3.2 Wall Mounting.....	366
35.3.3 Pole Mounting.....	369
35.3.4 Connecting RF Cables.....	373
36 27012544 Outdoor 2.4 GHz Dual-Polarized Directional Antenna (H18 V18 G18)	379
36.1 27012544 Technical Specifications.....	379
36.2 27012544 Installation Precautions.....	382
36.3 27012544 Antenna Installation.....	384
36.3.1 Accessories and Tools.....	384
36.3.2 Wall Mounting.....	384
36.3.3 Pole Mounting.....	391
36.3.4 Connecting RF Cables.....	398
37 27012545 Indoor 2.4 GHz and 5 GHz Linear-Polarized Omnidirectional Antenna (H360 V110 G4 and H360 V110 G5)	402
37.1 27012545 Technical Specifications.....	402
37.2 27012545 Antenna Installation.....	405
37.2.1 Accessories and Tools.....	405
37.2.2 Ceiling Mounting.....	406
37.2.3 Connecting RF Cables.....	406
38 27012565 Outdoor 2.4 GHz & 5 GHz Dual-Polarized Directional Antenna (H35 V35 G12 and H26 V26 G11)	409
38.1 27012565 Technical Specifications.....	409
38.2 27012565 Installation Precautions.....	412
38.3 27012565 Antenna Installation.....	413
38.3.1 Accessories and Tools.....	413
38.3.2 Wall Mounting.....	414
38.3.3 Pole Mounting.....	416
38.3.4 Connecting RF Cables.....	417
39 27012566 Outdoor 2.4 GHz & 5 GHz Dual-Polarized Directional Antenna (H32 V32 G13 and H15 V15 G17)	422
39.1 27012566 Technical Specifications.....	422
39.2 27012566 Installation Precautions.....	425
39.3 27012566 Antenna Installation.....	427
39.3.1 Accessories and Tools.....	427
39.3.2 Wall Mounting.....	427
39.3.3 Pole Mounting.....	430
39.3.4 Connecting RF Cables.....	431
40 27013413 Outdoor 5 GHz Dual-Polarized Directional Antenna (H45 V15 G15)	436

40.1 27013413 Technical Specifications.....	436
40.2 27013413 Installation Precautions.....	439
40.3 27013413 Antenna Installation.....	440
40.3.1 Accessories and Tools.....	440
40.3.2 Pole Mounting.....	441
40.3.3 Connecting RF Cables.....	445
41 27013571 Outdoor 2.4 GHz Dual-Polarized Directional Antenna (H18 V18 G18)	449
41.1 27013571 Technical Specifications.....	449
41.2 27013571 Installation Precautions.....	453
41.3 27013571 Antenna Installation.....	454
41.3.1 Accessories and Tools.....	455
41.3.2 Wall Mounting.....	455
41.3.3 Pole Mounting.....	458
41.3.4 Connecting RF Cables.....	463
42 27013718 Outdoor 2.4 GHz & 5 GHz Dual-Polarized Directional Antenna (H33 V33 G13 & H18 V18 G16)	467
42.1 27013718 Technical Specifications.....	467
42.2 27013718 Installation Precautions.....	471
42.3 27013718 Antenna Installation.....	473
42.3.1 Accessories and Tools.....	473
42.3.2 Wall Mounting.....	474
42.3.3 Pole Mounting.....	476
42.3.4 Connecting RF Cables.....	481
43 27013719 Outdoor 2.4 GHz & 5 GHz Dual-Polarized Directional Antenna (H33 V33 G13 & H30 V30 G13)	485
43.1 27013719 Technical Specifications.....	485
43.2 27013719 Installation Precautions.....	489
43.3 27013719 Antenna Installation.....	491
43.3.1 Accessories and Tools.....	491
43.3.2 Wall Mounting.....	492
43.3.3 Pole Mounting.....	494
43.3.4 Connecting RF Cables.....	499
44 27013720 Outdoor 2.4 GHz & 5 GHz Dual-Polarized Directional Antenna (H70 V70 G8 & H70 V70 G8)	503
44.1 27013720 Technical Specifications.....	503
44.2 27013720 Installation Precautions.....	507
44.3 27013720 Antenna Installation.....	509
44.3.1 Accessories and Tools.....	509
44.3.2 Wall Mounting.....	510
44.3.3 Pole Mounting.....	512

44.3.4 Connecting RF Cables.....	517
45 27013721 Outdoor 2.4 GHz & 5 GHz Single-Polarized Omnidirectional Antenna (H360 V30 G4 & H360 V15 G7).....	521
45.1 27013721 Technical Specifications.....	521
45.2 27013721 Installation Precautions.....	524
45.3 27013721 Antenna Installation.....	526
46 27013921 Rail Transportation 5 GHz Dual-Polarized Directional Antenna (H45 V15 G15).....	528
46.1 27013921 Technical Specifications.....	528
46.2 27013921 Installation Precautions.....	531
46.3 27013921 Antenna Installation.....	533
46.3.1 Accessories and Tools.....	533
46.3.2 Wall Mounting.....	533
46.3.3 Connecting RF Cables.....	535
47 27013955 Outdoor 5 GHz Dual-Polarized Directional Antenna (H25 V25 G16).....	539
47.1 27013955 Technical Specifications.....	539
47.2 27013955 Installation Precautions.....	542
47.3 27013955 Antenna Installation.....	544
47.3.1 Accessories and Tools.....	544
47.3.2 Wall Mounting.....	544
47.3.3 Connecting RF Cables.....	546
48 27013956 Outdoor 5 GHz Dual-Polarized Directional Antenna (H25 V25 G16).....	550
48.1 27013956 Technical Specifications.....	550
48.2 27013956 Installation Precautions.....	553
48.3 27013956 Antenna Installation.....	555
48.3.1 Accessories and Tools.....	555
48.3.2 Pole Mounting.....	556
48.3.3 Connecting RF Cables.....	560
49 27014279 Mining 2.4 GHz & 5 GHz Dual-Polarized Directional Antenna (H30 V30 G11&H15 V15 G15).....	563
49.1 27014279 Technical Specifications.....	563
49.2 27014279 Antenna Installation.....	567
49.2.1 Accessories and Tools.....	567
49.2.2 Pole Mounting.....	568
49.2.3 Connecting RF Cables.....	570
50 27014400 Indoor 2.4 GHz & 5 GHz Single-Polarized Omnidirectional Antenna (H360 V110 G3&H360 V110 G5).....	575
50.1 27014400 Technical Specifications.....	575
50.2 27014400 Antenna Installation.....	578

50.2.1 (Recommended) Ceiling Mounting..... 578

50.2.2 Wall Mounting.....581

50.2.3 Description of Mounting an AU on a Plasterboard Ceiling..... 583